



The WD 3 multi-purpose vacuum cleaner is super-powerful with a power consumption of just 1,000 watts. Its robust and impact-resistant plastic container has a capacity of 17 litres. The cartridge filter enables convenient vacuuming of wet and dry dirt, without filter replacement. The new suction hose and - not to be forgotten - the newly developed clips floor nozzle with mixed insert contribute to optimal dirt pick-up and ensure perfect cleanliness. The easily removable handle allows direct attachment of accessories to the suction hose. The practical parking position allows convenient parking of the suction tube and floor nozzle during working interruptions. WD 3 vacuum cleaners make light work of the toughest cleaning jobs with features such as blower function, "Pull & Push" locking system, ergonomic carrying handle and practical cable and accessory storage.




**WD 3**

- Newly developed accessories for perfect cleaning results
- Practical blower function
- Parking position

**Technical data**

<b>Order No.</b>	1.629-800.0	
<b>EAN code</b>	4039784943520	
<b>Actual suction power*</b>	<b>Air Watt</b>	200
<b>Energy use</b>	<b>W</b>	1000
<b>Container capacity</b>	<b>l</b>	17
<b>Container material</b>	Plastic	
<b>Power cable</b>	<b>m</b>	4
<b>Standard accessory ID</b>	<b>mm</b>	35
<b>Weight</b>	<b>kg</b>	5.5
<b>Dimensions (L × W × H)</b>	<b>mm</b>	388 × 340 × 503

**Equipment**

<b>Suction hose</b>	<b>m / mm</b>	2 / 35
<b>Removable handle</b>		■
<b>Suction tubes</b>	<b>piece(s) / m / mm</b>	2 × 0.5 / 35 / Plastic / -
<b>Wet and dry floor nozzle</b>		Clips
<b>Cartridge filter</b>		Standard
<b>Crevice nozzle</b>		■
<b>Paper filter bag</b>	<b>piece(s)</b>	1
<b>Blower function</b>		■
<b>Parking position</b>		■
<b>On-board accessory storage</b>		■

■ Included in delivery. \* Measured at the suction tubes according to the IEC 60312 standard.

# ACCESSORIES FOR WD 3

## 1.629-800.0



	Order No.	Price	Description
<b>Filter</b>			
Cartridge filter	1 6.414-552.0		Kärcher cartridge filter suitable for wet and dry use without filter replacement. ■
Paper filter bag	2 6.959-130.0		Two-ply paper filter bags with excellent filter capacity and high tear strength. Contains: 5 bags □
<b>Accessory kits</b>			
Brush car set	3 2.863-221.0		The suction brush set allows thorough car interior cleaning that is appropriate to the material being cleaned, from dashboards to foot mats and upholstered surfaces. For all Home & Garden multi-purpose vacs. □
Car interior cleaning kit	4 2.863-225.0		Optimised car interior cleaning kit for complete car interior cleaning: from the dashboard to car seats, upholstered surfaces, foot mats, crevices, gaps and car boots. □
Household Kit	5 2.863-002.0		The Home Kit includes a switchable dry vacuum floor nozzle and an upholstery nozzle. The practical accessory kit is suitable for all Kärcher multi-purpose vacuum cleaners from the Home & Garden area. □
Vacuum Kit for power tools	6 2.863-112.0		Flexible suction hose (1 m) including adapter for connecting hose to the dust exhaust connection of power tools (e.g. jigsaws, grinders, drills, planes, etc.) For clean DIY. □
Car interior cleaning Kit	7 2.862-128.0		Extensive accessory kit for all jobs in the car. For cleaning car boots, footwells, dashboards, seats, side pockets, foot-mats, etc. □
<b>Nozzles</b>			
Extra long crevice nozzle	8 2.863-223.0		Fully redesigned, extra long crevice nozzle. Ideal for hard-to-reach places inside the car (for example gaps and crevices). Suitable for all Kärcher Home & Garden multi-purpose vacs. □
Car nozzle/suction nozzle for large areas	9 2.863-145.0		Handy car vacuuming tool for quick and easy cleaning – from the footwell to the boot. □
Suction brush black	10 2.863-147.0		Brush with extra soft bristles for gentle cleaning of sensitive surfaces in the car, e.g. dashboards or centre consoles. □
Extra long crevice nozzle	11 2.863-144.0		Extra-long crevice tool for difficult to reach areas such as crevices, gaps, cracks and similar, e.g. between upholstery, side pockets in cars or between walls and furniture. □
Switchable wet and dry vacuum nozzle with integrated parking nib	12 2.863-000.0		Switchable wet and dry vacuum nozzle for perfect dirt intake. Easy adaptation to wet or dry dirt using foot switch. For all Kärcher Home & Garden multi-purpose vacuum cleaners. □
Suction brush with hard bristles	13 2.863-146.0		Brush for thoroughly cleaning car upholstery and carpets. Hard brush easily removes dried dirt. □
<b>Special applications</b>			
Ash filter/coarse dirt filter Basic	14 2.863-139.0		Coarse dirt/ash filter for cleaning fireplaces, tiled stoves, barbecues, sauna ovens, etc., as well as removing coarse dirt. □
Ash filter/coarse dirt filter Premium	15 2.863-161.0		Premium coarse dirt/ash filter with fine filter suitable for cleaning fireplaces, tiled stoves, barbecues, sauna ovens, etc., as well as removing coarse dirt. □
3.5 m suction hose extension	16 2.863-001.0		The 3.5 m long suction hose extension is suitable for all Kärcher multi-purpose vacuum cleaners from the Home & Garden area and ensures a larger working radius and greater free movement. □

■ Included in delivery. □ Available accessories.

# ACCESSORIES FOR WD 3 1.629-800.0



		<b>Order No.</b>					<b>Price</b>	<b>Description</b>	
Extension suction tube	17	2.863-148.0						Practical extension suction tube for greater flexibility. Suction tube can be extended for difficult to reach areas, e.g. high ceilings.	<input type="checkbox"/>
Drilling dust tool Home & Garden *int	18	2.863-234.0							<input type="checkbox"/>

■ Included in delivery.    □ Available accessories.