



## WRE 18-55 Battery Set

Battery and battery charger included: the WRE 18 -55 Battery Set weed remover for the superficial removal of moss and weeds. Ideal for paths, terraces and entrances.



### 1 Innovative nylon brush

- Specially aligned nylon bristles and a high brush rotational speed for the superficial removal of dry moss and weeds.



### 2 Proximity assist

- The 360° rotatable hemisphere at the cap promotes the optimal effortless working posture.



### 3 Bristle replacement without tools

- For easily changing the worn bristle rink.



### 4 Swivelling cleaning head

- Angles can be individually adjusted to suit different cleaning situations and people of different heights.



## WRE 18-55 Battery Set

- 18 V Kärcher Battery Power platform device
- Battery-powered, battery and battery charger included in the scope of supply

### Technical data

<b>Order no.</b>	1.445-245.0	
<b>EAN code</b>	4054278693644	
<b>Brush speed</b>	rpm	2300 - 2800
<b>Brush diameter</b>	mm	180
<b>Bristle material</b>	Nylon	
<b>Battery platform</b>	18 V battery platform	
<b>Voltage</b>	V	18
<b>Capacity</b>	Ah	2.5
<b>Battery type</b>	Lithium-ion replacement battery	
<b>Performance per battery charge</b>	m <sup>2</sup>	max. 15 (2,5 Ah) / max. 30 (5,0 Ah)
<b>Runtime per battery charging</b>	min	approx. 15 (2,5 Ah) /
<b>Battery charging time with standard charger</b>	h	5
<b>Charging current</b>	A	0.5
<b>Power supply for battery charger</b>	V / Hz	100 - 240 / 50 - 60
<b>Weight without accessories</b>	kg	2.85
<b>Dimensions (L × W × H)</b>	mm	1320 × 230 × 380

### Equipment

<b>Battery</b>	18 V / 2.5 Ah Battery Power battery (1 pc.)	
<b>Battery charger</b>	18 V Battery Power standard charger (1 pc.)	
<b>Bristle rink</b>	■	
<b>Splash guard</b>	■	
<b>Parking position</b>	■	
<b>Aluminium telescopic handle</b>	■	
<b>Hanging storage loop</b>	■	
<b>Safety switch</b>	■	
■ Included in the scope of supply.		

# WRE 18-55 BATTERY SET 1.445-245.0

**KÄRCHER**



		Order no.					Price	Description	
<b>Batteries</b>									
Battery Power 18/25	1	2.445-034.0						18 V / 2.5 Ah Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher battery platform.	■
Battery Power 18/50	2	2.445-035.0						18 V / 5.0 Ah Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher battery platform.	□
<b>Weed remover</b>									
Bristle strap weed remover	3	2.445-243.0						Replacement bristle strap made from nylon for effortlessly removing weeds, suitable for the ergonomic WRE 18-55 and WRE 4 Battery weed removers from Kärcher.	■
<b>Battery chargers</b>									
Fast Charger Battery Power 18 V	4	2.445-032.0						The fast charger charges the 18 V/2.5 Ah Kärcher Battery Power exchangeable battery to 80% in just 44 minutes and can be used for all batteries on the 18 V Kärcher battery platform.	□
<b>Starterkit Batteries and Battery chargers</b>									
Starter kit Battery Power 18/25	5	2.445-062.0						Battery Power 18/25 Starter Kit incl. 18 V/2.5 Ah Battery Power exchangeable battery with innovative Real Time Technology and 18 V fast charger. For all devices on the 18 V Kärcher battery platform.	□
Starter kit Battery Power 18/50	6	2.445-063.0						Incl. 18 V / 5.0 Ah Kärcher Battery Power exchangeable battery and 18 V fast charger: The Battery Power 18/50 Starter Kit for use in all devices on the Kärcher 18 V battery platform.	□
<b>Accessories Garden Tools general</b>									
Shoulder belt	7	2.445-242.0						Lighten your load with the comfortable and ergonomic shoulder strap, enabling you to work for long periods without tiring. Compatible with many of Kärcher's battery-powered garden tools.	□

■ Included in the scope of supply. □ Available accessories.